

# **Cerberus® PRO**

# 252-Point and 504-Point Addressable **Fire Alarm Control Panel** Models FC922 | FC924

# **Architect & Engineer Specifications**

#### □ Addressable fire alarm control panel (FACP) intended for mid-size building applications

- □ Comprised of the following system components:
  - Operating units
  - Periphery boards
  - **Power supplies**
  - System enclosures 'Walk Test'
- □ System features:
  - Supports 252-to-504 addressable devices:
    - One (1) to four (4) 'Class B'; one (1) to two (2) 'Class A' for Model FC922
    - One (1) to eight (8) 'Class B'; one (1) to four (4) 'Class A' for Model FC924
- □ 10,000-event history-logging capability
- □ Includes one (1) 'Class A' or two (2) 'Class B' notification appliance circuits (NACs)
- □ Resettable and non-resettable 24VDC, [nominal] auxiliary power
- □ Connectivity to a leased-line / city-tie module
- □ Releasing module supports activation of releasing valves in pre-action / deluge systems / agent release
- Off-normal warning message prior to reset
- □ Fast and easy set-up with auto-configuration feature
- □ Networkable up to 32 panels using CV Web or up to 16 panels using SafeDLink
- Cerberus® DMS Danger Management Station can monitor and control up to 32 Models FC922 and FC924 FACPs
- □ Supports multiple global displays
- Digital alarm communication transmitter (DACT)
- UL 864 10th Edition Listed, ULC-S527 Listed
- □ FM, CSFM & NYC Fire Department Approved



### Product Overview

The Cerberus PRO 252-point (Model FC922) / 504-point (Model FC924) addressable FACP is designed to meet the fire-protection needs of mid-size buildings. This advanced FACP offers features typically required in mid-size buildings in a package that is easy to install and competitively priced.

Additionally, Models FC922 and FC924 are networkable, allowing the systems to fulfill the growing fire-protection needs of the building. The programming software for the 252/ 504-point fire systems is held in flash electrically erasable programmable read-only memory (EEPROM).

The following Cerberus PRO system components are used in the 252-point / 504-point FACP:

- **Operating units** •
- Periphery boards
- Power supplies .
  - System enclosures

Other options are available to meet specific needs.

Models FC922 and FC924 are FM (#3010); CSFM(#7165-0067:0259) and FDNY (#6104) Approved.



Model FC922

# **Specifications**

# **Operating Interface Unit**

The Operating Interface Unit (Model FCM2018-U3 or Model FCM2019-U3) functions as the operating interface and central microprocessor for Models FC922 and FC924 with up to 10,000 event history log.

Either operating interface unit provides multi-use capability for each enduser to efficiently 'Acknowledge' events; to quickly control the NACs of the FACP, and to permit a manual reset of the respective system. Detailed data about the nature and location of the events can also be displayed, via a backlit, 2'' - x - 4 - 3/4'' (5.1 cm. -x - 12.1 cm.) LCD screen and the four-way navigation push button at the top of the FACP.

**Note:** For applications in Canada that require a Desigo operating unit with LEDs, Model FCM2035-U3 must be ordered.

# **Periphery Boards**

The periphery boards (Models FCI2016-U1 and FCI2017-U1) serve as the main operating components for the 252 / 504-point FACP. Each module operates and monitors input-device identity; as well as controls the signaling-line circuits that communicate with smoke detectors and other field devices (i.e. –C-NET).

# **Power Supplies**

All functions are supported by the power supplies (Model FP2011-U1 or Model FP2012-U1), which therefore eliminate the need for external power supplies.

Further, the 170-Watt power supply (Model FP2011-U1) and 300-Watt power supply (Model FP2012-U1) provide primary, 24VDC nominal power for normal operation to Models FC922 and FC924. Both power supplies are filtered and regulated. Model FP2011-U1 is rated at 6.5 Amps, and the rating for Model FP2012-U1 is 11.5A.

The 170-Watt power supply incorporates a 4.0A, nonresettable slow-blow fuse on the primary input, and includes a built-in AC-line filter for surge and noise suppression. Model FP2011-U1 mounts in the FACP enclosure, and there are no serviceable Cerberus PRO parts to be maintained.

The 300-Watt power supply incorporates two (2) 6.3A replaceable, non-resettable slow-blow fuses on the primary input and includes a built-in AC line filter for surge and noise suppression. Model FP2012-U1 mounts in the FACP's enclosure, and there are no serviceable Cerberus PRO parts to be maintained.

# System Enclosures

The Cerberus PRO fire-alarm enclosures and their accessories provide a complete set of hardware for mounting all Cerberus PRO main-system and remote terminal cards and modules.

The hardware allows this Cerberus PRO system to be configured for a variety of applications, as well as for future system upgrades. Included in the enclosure series are back box and door sets; removable mounting plates and clear lenses, as well as blank plates for use with the enclosure doors.

All enclosures come with ground straps for the inner and outer doors, shield termination lugs, grounding lugs, and tie wrap lances for securing wire. All Cerberus PRO two heightunit (2HU) enclosures can also mount system back-up batteries to 33AH in capacity.

Models FC922 and FC924 utilize a two-height-unit enclosure. The following components comprise a complete two-height-unit enclosure:

- One (1) back box, (Model FHB2002-U1 / R1)
- One (1) or two (2) inner doors, (Models FHD2004-U1 or FHD2005-U1)
- One (1) outer door, (Model FHD2002-U3 / R3 or FHD2003-U3 / R3)
- One (1) or two (2) clear windows, (Model FHD2006-U1)

The approximate size for each two-height-unit enclosure is: 27.5" (70cm.) high; 21.5" (54.6cm.) wide, and 5.75" (14.6cm.) deep. The weight, without any attached components, is approximately 6.3 Lbs. (2858 g).

#### **Note:** One (1) window is installed for Model FHD2002-U3 / R3 outer door, and two (2) windows are required for Model FHD2003-U3 / R3

Additionally, the two-height-unit enclosure supports the following optional components:

- Enclosure trim kit (for flush-mounting)
- Battery bracket (to comply with seismic certification)
- DIN rail kit (provides connection between internalsystem wiring and field wiring

# **Optional Accessories**

#### **Digital Alarm Communication Transmitter (DACT)**

The DACT is used to provide communication between Models FC922 and FC924 and with either a central or remote monitoring station. The Model FCA2015-U1 module mounts directly on the back enclosure and connects to the periphery boards. The DACT enables remote transmission of alarms and events via a public telephone line.

#### **Releasing Module**

The releasing module (Model XCI2001-U1) supports activation of releasing valves in pre-action / deluge systems (including double-interlock pre-action systems, or Sinorix<sup>®</sup> Engineered Fire Suppression systems). Activation can be event-controlled or performed by addressable manual pull stations. The releasing module is installed on the periphery board and supports `Class B' releasing circuits.

When installed on Models FC922 / FC924, the releasing module contains an integral manual-disconnect switch for releasing circuits. This essential feature protects the releasing circuits from accidental discharge during maintenance.

# Leased-Line / City-Tie Module

The Leased-Line / City-Tie module (Model FCI2020-U1) is used as an optional module, providing a local-energy output for municipal call-box connection.

Model FCI2020-U1 also gives a reverse-polarity output for leased-line connection. Model FCI2020-U1 is installed on the periphery board for Models FC2025 and FC2050 FACPs.

When used for connection to a municipal call box, the citytie function supports Alarm-event transmission. When used for leased-line connection, the module supports two (2) leased telephone lines for transmitting *Alarm*, *Trouble* and *Supervisory* events.

#### **Battery Disconnect Module**

The Battery Disconnect Module (Model FCA2032-U1) is specifically designed to disconnect the backup battery on the Cerberus PRO 252 / 504-point addressable FACP when its voltage drops below 19VDC. Model FCA2032-U1's cut-off capability prevents the battery from operating beyond its normal power level for basic system operation.

#### Hardware Migration Kit

The Cerberus PRO 922/924 panel offers support for Siemens legacy addressable and conventional systems. Model FHA2056-series kits are specifically designed for the seamless transition of an existing Siemens FS-250 (FireSeeker) or MPC6000 control panel into a fully operational 50 | 252 or 504-point addressable Cerberus PRO fire-alarm FACP, [FC901 | FC922 or FC924], respectively. Each chipment of the Model EHA2056-series kits contains

Each shipment of the Model FHA2056-series kits contains the following pieces of equipment:

- One (1) outer door
- One (1) inner door
- One (1) hinge-assembly bracket
- One (1) back plate
- One (1) inner-door bracket

**NOTE:** The five (5) items that comprise one (1) Model FHA2056-series hardware-migration kit cannot be ordered individually.

Model FHA-MIQKIT-04/-05 offers support for legacy MXL and MXL-IQ peripherals using the FCL2004 device interface module.

#### **Specifications (cont.)**

#### Hardware Migration Kit (cont.)

This allows the user to configure a Cerberus PRO panel to communicate to older addressable devices, offering a seamless migration solution to the latest technology system.

#### Network Module

The C-WEB network module (Model FN2001-U1) is used to network up to 16 FACPs, or one (1) fire terminal, via the C-NET system bus.

Model FN2001-U1 is plugged into the Operating Units (Models FCM2018-U3 /R3 and FCM2019-U3 /R3). Model FN2001-U1, which connects to a system input / output bus, has ground-fault monitoring, as well as an integrated degrade-mode feature. Redundant networking is done with one (1) network module per FACP [Simple-Loop Trouble].There is electrical isolation between the system bus and FACP.

#### **Remote Display Terminals**

The Remote Display Terminals (Models FT2014-U3 /R3and FT2015-U3 /R3) are remote annunciators that's how the existing status of Models FC922 / FC924. The remote display terminals (Models FT2014-U3/R3 and FT2015-U3/R3) are remote annunciators which can be configured as global displays, and indicate real-time system status.

Light-emitting diodes (LEDs) will illuminate for any given *Alarm, Supervisory and Trouble* Cerberus PRO-system event. The LCD screen will give details of the event in alphanumeric form. The display screen can be scrolled, via the four-way navigation button, to reveal additional events.

Model FT2014-U3 /R3 is a display-only remote annunciator that has one (1) button used to silence the local sounder. Model FT2015-U3 /R3 has three (3) control buttons for `acknowledging' events, `silencing' audible circuits and `resetting' the system. Additionally, there are three (3) user-programmable buttons available. Model FT2015-U3 /R3 has an integral key switch that enables the control buttons to operate.

The remote display terminals are remotely connected to Models FC922 and FC924, via the RS—485 interface. Models FC922 and FC924 require the Model FCA2016-U1 RS—485 module to provide communication to the remote display terminals. Model FCA2016-U1 supports Style 4 or Style 6 wiring. Up to eight (8) modules can be supported on a RS—485 bus.

The remote display terminals require 24VDC [nominal] power, and the necessary power can be provided from this Cerberus PRO FACP or from another UL / ULC Listed, 24VDC power source.

**Note:** A Model FHD2012-U1 inner door can be optionally purchased in UL markets. The inner door mounts with the optional Model FT201x Series Remote Display terminals. Having a Model FHD2012-U1 inner door installed can assist in preventing unauthorized access to the RDT.

#### S-series License Keys

The S1 license key (Model FCA2033-A1) allows for virtual monitoring and control between a 252 / 504-point addressable fire-only panel and a personal computer.

The S2 license key (Model FCA2034-A1) is a BACnet output, and is used for monitoring-only purposes by a 3rd-party system for life-safety objects.

The S3 license key (Model FCA2035-A1) is a combination license key that allows for virtual monitoring and control, as well as for distribution of BACnet (monitoring-only).

# S-series License Keys (cont.)

A four-digit personal identification number (PIN) must be used in order to prevent unauthorized access.

#### **Tabular Annunciators**

Tabular annunciators allow system events sent from Cerberus PRO addressable panels to be displayed remotely in real-time.

The Model FT2008 series of tabular annunciators has 16 zones, and the Model FT2009 series uses 96 LEDs for 32 zones.

Up to two(2) light-emitting diodes (LEDs) can be used per zone. Tabular annunciators provide outputs for system and zone status, and are orderable in either black or red.

#### **Remote Peripheral Module**

The Remote Peripheral Module (Model FCA2018-U1) provides a means of connecting a Desigo FACP to a parallel printer (Model PAL-1) for creating hard copies of system-status and configuration reports.

Model FCA2018-U1 is a supervised, intelligent module that has built-intransient protection and plain-decimal addressing.

Model FCA2018-U1 is remotely connected to the Model FCA2016-U1 RS—485 communication bus from any Desigo Fire Safety system enclosure. Model FCA2018-U1 uses 'Class B' (Style 4) or 'Class A' (Style 6) wiring, and provides two (2) RS—232 serial ports and a one (1)parallel port, thus connecting to Model PAL-1.

#### **LED Annunciator Driver**

The Model FT2007-U1 LED Annunciator Driver provides custom graphic annunciators on addressable Cerberus PRO FACPs. This optional system module provides 96 highly programmable outputs to drive LED indicators. There are 16 inputs to accommodate user-system commands: *Silence, Unsilence, Reset, Acknowledge* and *Lamp Test*.

Model FT2007-U1 is supervised via aRS-485 interface. A maximum eight (8) modules are allowed on each RS-485 communication bus.

# Graphics Input / Output Driver

The Graphics Input / Output (I/O) Driver (ModelFT2003-U1) is a fire-system accessory on the RS-485(Model FCA2016-U1) interface circuit. Model FT2003-U1, which serves as a combination standalone remote display / operating unit, provides the ability to build a graphic annunciator for the Desigo Fire Safety 252 /504-point addressable FACPs.

Model FT2003-U1, which comes without an enclosure or display panel, consists of an indicator printed circuit board (PCB) and a driver PCB that are screwed together.

Each I/O driver has 32 outputs to drive highly programmable LEDs, and also contains 16 inputs to accommodate user-defined system commands, such as: *Acknowledge; Silence or Reset.* 

# NAC Expansion Module

The NAC expansion module (Model FCI2011-U1) provides either of the following additional NACs to a Cerberus PRO 252 / 504-point FACP:

- one (1) Class A', or
- two (2) Class B' NACs

Each NAC is rated at 3 Amps. Each NAC expansion module is monitored for open-line and short-circuit conditions.

# Temperature and Humidity Range

Models FC922 and FC924 are UL 86410th Edition and ULC-S527 Listed for indoor dry locations within a temperature range of 120+/ 3°F (2°C) to 32+/ 3°F (0+/ 2°C) and a relative humidity of 93+/ 2% at a temperature of 90+/ 3°F (32+/ 2°C).

|                  | Details for Ordering |   |  |  |
|------------------|----------------------|---|--|--|
| MODEL OR<br>TYPE | PART<br>NUMBER       | PRODUCT   |  |  |
| FCI2020-U1       | S54400-A57-A1        | Leased-Line / City -Tie Module  |  |  |
| FCM2018-U3       | S54400-C40-A2        | Operating Interface Unit  |  |  |
| FP2011-U1        | 500-450222           | 170-Watt Power Supply   |  |  |
| FP2012-U1        | S54400-Z60-A1        | 300-Watt Power Supply   |  |  |
| FT2007-U1        | S54400-A142-A1       | LED Annunciator Driver  |  |  |
| FT2008-U1        | S54400-A143-A1       | 16-Zone Tabular Annunciator, Black  |  |  |
| FT2008-R1        | S54400-A144-A1       | 16-Zone Tabular Annunciator, Red  |  |  |
| FT2009-U1        | S54400-A145-A1       | 32-Zone Tabular Annunciator, Black  |  |  |
| FT2009-R1        | S54400-A146-A1       | 32-Zone Tabular Annunciator, Red  |  |  |
| FT2014-U3        | S54400-B80-A1        | Remote Display Terminal, Black  |  |  |
| FT2014-R3        | S54400-B73-A1        | Remote Display Terminal, Red  |  |  |
| FT2015-U3        | S54400-B88-A1        | Remote Display Terminal, Black  |  |  |
| FT2015-R3        | S54400-B16-A1        | Remote Display Terminal, Red  |  |  |
| FTI2001-U1       | S54400-A58-A1        | Fire Terminal Board   |  |  |
| FCA2015-U1       | S54400-A63-A1        | Digital Alarm Communication<br>Transmitter  |  |  |
| FN2001-U1        | S54400-A60-A1        | C-WEB Network Module  |  |  |
| FCA2016-U1       | S54400-A39-A1        | RS-485 Interface  |  |  |
| FCA2018-U1       | S54400-A65-A1        | Remote Peripheral Module  |  |  |
| FCA2032-U1       | S54400-B145-A1       | Battery Disconnect Module   |  |  |
| FCA2033-U1       | S54400-P154-A1       | License Key (S1) for remote access  <br>remote view   remote operation                    |  |  |
| FCA2034-U1       | S54400-P155-A1       | License Key (S2) for BACnet output<br>(monitoring only)                                   |  |  |
| FCA2035-U1       | S54400-P156-A1       | License Key (S3) for remote access  <br>remote view   remote operation  <br>BACnet output |  |  |
| FCI2011-U1       | S54400-A54-A1        | NAC Expansion Module  |  |  |
| FCI2016-U1       | S54400-A55-A1        | 252-Pt. Periphery Board   |  |  |
| FCI2017-U1       | S54400-A56-A1        | 504-Pt. Periphery Board   |  |  |
| XCI2001-U1       | S54400-A69-A1        | Releasing Module  |  |  |
| FCM2019-U3       | S54400-C41-A2        | Operating Interface Unit<br>[with LED]  |  |  |
| FCM2022-U3       | S54400-C44-A2        | Blank Option Module   |  |  |
| FCM2023-U3       | S54400-C45-A2        | LED Option Module<br>[ Red / Yellow bi-color LED; one<br>(1)Yellow LED ]                  |  |  |
| FCM2034-U3       | S54400-C138-A1       | LED Option Module:<br>[ Red / Yellow bi-color LED; one<br>(1)Yellow LED ]                 |  |  |

| Details for Ordering (cont.) |                |  |  |  |
|------------------------------|----------------|--|--|--|
| MODEL OR<br>TYPE             | PART<br>NUMBER | PRODUCT  |  |  |
| FN2006-U1                    | S54400-A61-A1  | Single-Mode Fiber-Optic Module   |  |  |
| FN2007-U1                    | S54400-A62-A1  | Multi-Mode Fiber-Optic Module  |  |  |
| FHB2001-U1                   | S54400-B47-A1  | One-Height-Unit Back Box, Black  |  |  |
| FHB2001-R1                   | S54400-B47-A2  | One-Height-Unit Back Box, Red  |  |  |
| FHB2002-U1                   | S54400-B48-A1  | Two-Height-Unit Back Box, Black  |  |  |
| FHB2002-R1                   | S54400-B48-A2  | Two-Height-Unit Back Box, Red  |  |  |
| FHD2001-U3                   | S54400-B45-A1  | One-Height-Unit Outer Door, Black  |  |  |
| FHD2001-R3                   | S54400-B40-A1  | One-Height-Unit Outer Door, Red  |  |  |
| FHD2002-U3                   | S54400-B32-A1  | Two-Height-Unit Outer Door<br>[with one (1) window], Black                           |  |  |
| FHD2002-R3                   | S54400-C53-A1  | Two-Height-Unit Outer Door<br>[with one (1) window], <mark>Red</mark>                |  |  |
| FHD2003-U3                   | S54400-C42-A1  | Two-Height-Unit Outer Door<br>[with two (2) windows], Black                          |  |  |
| FHD2003-R3                   | S54400-B46-A1  | Two-Height-Unit Outer Door<br>[with two (2) windows], <mark>Red</mark>               |  |  |
| FHD2004-U1                   | S54400-B52-A1  | Inner door, Black  |  |  |
| FHD2005-U1                   | S54400-B53-A1  | Inner door, Solid Black  |  |  |
| FHD2006-U1                   | S54400-C46-A1  | Clear-lens window  |  |  |
| FHD2012-U1                   | S54400-C135-A1 | Optional inner door<br>[for housing a Model FT201-series<br>display terminal], Black |  |  |
| FHA2056-U1                   | S54400-B18-A1  | Cerberus PRO Hardware<br>Migration Kit, Black  |  |  |
| FHA2056-R1                   | S54400-B19-A1  | Cerberus PRO Hardware<br>Migration Kit, <mark>Red</mark>                             |  |  |
| FHAMIQKIT-04                 | S54400-C24-A1  | MXL-IQ Mechanical Migration Kit,<br>Black  |  |  |
| FHAMIQKIT-05                 | S54400-C25-A1  | MXL-IQ Mechanical Migration Kit,<br>Red  |  |  |
| FHAMIQKIT-03                 | S54400-K1-A1   | One (1) PMI cable &<br>One (1) Expansion Cable                                       |  |  |
| FHAMIQKIT-01                 | S54400-A66-A1  | One (1) FCL2004 Module<br>with PMI Cable   |  |  |
| FHAMIQKIT-02                 | S54400-A67-A1  | One (1) FCL2004 Module<br>with Expansion Cable                                       |  |  |
| FCL-MXLPLATE                 | S54400-B153-A1 | Mounting Bracket for<br>FCL2004 (2HU/USCG)   |  |  |
| FH2072-UA                    | S54433-A5- A1  | Universal Battery Cabinet  |  |  |
| FTH2073-UA                   | S54433-A6- A1  | Universal Annunciator Cabinet  |  |  |
| FH2072-UA                    | S54433-A5- A1  | Universal Battery Cabinet  |  |  |
| FTH2073-UA                   | S54433-A6- A1  | Universal Annunciator Cabinet  |  |  |

| Electronics Package |                |  |  |  |
|---------------------|----------------|--|--|--|
| Model<br>Or<br>Type | PART<br>NUMBER | PRODUCT  |  |  |
| FC922-US            | S54400-C14-A1  | 252-Point Fire System with 170 Watt<br>Power Supply and standard<br>operator interfaces.                     |  |  |
|                     |                | Includes:  |  |  |
| FC924-US            | S54400-C15-A1  | 504-Point Fire System with 170 Watt<br>Power Supply and standard<br>operator interfaces.                     |  |  |
|                     |                | Includes:  |  |  |
| FC922-UE            | S54400-C16-A1  | 252-Point Fire System with 170 Watt<br>Power Supply and standard operator<br>interfaces. (with 24-zone LEDs) |  |  |
|                     |                | Includes:  |  |  |
| FC924-UE            | S54400-C17-A1  | 504-Point Fire System with 170 Watt<br>Power Supply and standard operator<br>interfaces. (with 24-zone LEDs) |  |  |
|                     |                | Includes:  |  |  |
| FT924-US            | S54400-C18-A1  | Network Terminal w/<br>standard operator interface   |  |  |
|                     |                | Includes:  |  |  |
| FT924-UE            | S54400-C19-A1  | Network Terminal w/ standard<br>operator interface<br>(with 24-zone LEDs)<br>Includes:                       |  |  |
|                     |                | <ul> <li>FTI2001-U1 (1 Qty.)</li> <li>FCM2019-U3 (1 Qty.)</li> </ul>   |  |  |
| FC922-UT            | S54400-C20-A1  | 252-Point Fire System with 300 Watt<br>Power Supply and standard<br>operator interfaces                      |  |  |
|                     |                | Includes:  |  |  |
| FC924-UT            | S54400-C21-A1  | 504-Point Fire System with 300 Watt<br>Power Supply and standard<br>operator interfaces                      |  |  |
|                     |                | Includes:  |  |  |

| Electronics Package (Cont.)     |                |  |  |
|---------------------------------|----------------|--|--|
| MODEL<br>OR<br>TYPE             | Part<br>Number | PRODUCT  |  |
| FC922-UF                        | S54400-C22-A1  | 252-Point Fire System with 300 Watt<br>Power Supply and standard operator<br>interfaces(with 24-zone LEDs) |  |
|                                 |                | Includes:<br>FP2012-U1 (1 Qty.)<br>FCI2016-U1 (1 Qty.)<br>FCM2019-U3 (1 Qty.)                              |  |
| FC924-UF                        | S54400-C23-A1  | 504-Point Fire System with 300 Watt<br>Power Supply and standard operator<br>interfaces(with 24-zone LEDs) |  |
|                                 |                | Includes:<br>FP2012-U1 (1 Qty.)<br>FCI2017-U1 (1 Qty.)<br>FCM2019-U3 (1 Qty.)                              |  |
| Canadian-Specific Applications: |                |  |  |
| FCM2035-U3                      | S54400-C140-A1 | Enhanced Operating Unit<br>(with LEDs)   |  |

**Note:** Refer to Data Sheet# 9800 for Canadian-Specific Electronics Package.

| Related Documentation   |                     |  |  |
|---|---------------------|--|--|
| Product   | Datasheet<br>Number |  |  |
| Cerberus PRO Operating Interface Units                        | 9801                |  |  |
| Cerberus PRO System Periphery Boards                          | 9802                |  |  |
| Cerberus PRO Fire Terminal and Equipment                      | 9803                |  |  |
| Cerberus PRO Digital Alarm Communicator<br>Transmitter (DACT) | 9804                |  |  |
| C-WEB Network Module  | 9805                |  |  |
| 170-Watt and 300-Watt Power Supplies                          | 9806                |  |  |
| Cerberus PRO Fire-Alarm Enclosures and Equipment              | 9807                |  |  |
| NAC Expansion Module  | 9808                |  |  |
| Releasing Module  | 9809                |  |  |
| Leased-Line / City-Tie Module                                 | 9810                |  |  |
| Cerberus PRO Remote Peripheral Module                         | 9811                |  |  |
| Cerberus PRO Remote Display Terminals                         | 9812                |  |  |
| Single / Multi-Mode Fiber-Optic Modules                       | 9814                |  |  |
| LED / Blank Option Modules                                    | 9816                |  |  |
| Battery Disconnect Module                                     | 9819                |  |  |
| S-series license keys   | 9820                |  |  |
| Cerberus PRO Marine Fire and Detection Equipment              | 9822                |  |  |
| Cerberus PRO LED Annunciator Driver                           | 9824                |  |  |
| Cerberus PRO 16 & 32 -Zone Tabular Annunciators               | 9825                |  |  |
| Cerberus PRO Migration Hardware Kit                           | 9826                |  |  |

<u>NOTICE</u> – The information contained in this data-sheet document is intended only as a summary, and is subject to change without notice. The product(s) described here has/have a specific instruction sheet(s) that cover various technical, limitation and liability information.

Copies of install-type, instruction sheets – as well as the *General Product Warning and Limitations* document, which also contains important data, are provided with the product, and are available from the Manufacturer.

Data contained in the aforesaid type of documentation should be consulted with a fire-safety professional before specifying or using the product.

Any further questions or assistance concerning particular problems that might arise, relative to the proper functioning of the equipment, please contact the Manufacturer.

# **Cerberus® PRO**

Siemens Industry, Inc. Smart Infrastructure - Building Products 2 Gatehall Drive • Parsippany, NJ 07054 Tel: (973) 593-2600

> March - 2023 (Rev. 10)

